

POLYDEF Ag+ PS

PRODUCT DATA SHEET

POLYDEF Ag+ PS is a concentrated masterbatch formulated from silver particles (Ag) designed for GPPS and HIPS-based plastics that adds bactericidal properties to the finished polymer elements.

The presence of silver in the protected polymer ensures a biocidal effect by inhibiting the metabolic pathways of microorganisms, contributing to the elimination of sources of unpleasant smells and the extension of the lifetime of the material. The additive is environmentally friendly, does not affect the physical properties of the polymers and does not cause degradation of the protected material. The component provides long-lasting microbiological protection (microbiological efficacy of $\geq 99.98\%$), as well as enhances the safety and attractiveness of the product. The additive is also very stable at high temperatures and in high humidity compared to traditionally used biocides.

General information

Polydef Ag+ PS is added to the finished product during manufacture. The granules provide antimicrobial properties and should not affect the basic colour or surface finish of the product. The active substances do not degrade or leach. The additive is designed to exhibit constant activity throughout the product life cycle.

Recommended dosage

To achieve bactericidal results, it is recommended to use a dosage of 4-6% by weight in proportion to the final polymer composite. To obtain fungicidal effects, a 6% weight dosage is advised. It is advisable to validate the efficacy of the antibacterial additive before releasing the product to the market.

Test procedure

The analysis is a quantitative test designed to assess the performance of antimicrobial properties. Test samples are incubated with a bacterial suspension for 24 hours at 37°C. The average number of viable bacterial cells and the percentage reduction of the selected microorganism are then calculated.

Microbiological efficacy

Microbiological efficacy Microbiological properties were subjected to testing in accordance with ISO 22196 *Measurement of antibacterial activity on plastics and other non-porous surfaces*, against the following microorganisms:

- Escherichia coli ATCC 8739
- Staphylococcus aureus ATCC 6538

The reduction efficacy of more than 90% has been confirmed.

Storage

The granules have been developed in a manner that ensures the highest stability during storage and use.

Be aware that silver-containing materials may be sensitive to light and electromagnetic fields. Insufficiently mixed product may cause discolouration in the finished goods, which is why it is the responsibility of the manufacturer of the final component to fully assess it under normal conditions of use.

Before use

It is important, as with all chemicals, to read the product data sheet before use.

Before applying the product, always ensure that you have the latest information. For more information, contact us at kontakt@smartnanotech.com.pl.

The information presented in this document is provided to the best of our knowledge and with due diligence to ensure that it is accurate and up-to-date. Smart Nanotechnologies S.A. shall not be liable for any damages arising directly or indirectly from the use of the information contained herein. The document is issued subject to the user determining the safety and suitability of the product before use. Since regulations are country-specific, local information should be consulted before marketing the product.

PRODUCER:

Smart Nanotechnologies S.A.
Karola Olszewskiego 25,
32-566 Alwernia, Polska

smartnanotech.com.pl
phone: +48 12 25 89 395



POLYDEF Ag+ PS

POLYMER MATRIX DATA SHEET



POLYDEF Ag+ PS is a concentrated masterbatch formulated from silver particles (Ag) designed for GPPS and HIPS-based plastics that adds bactericidal properties to the finished polymer elements.

The presence of silver in the protected polymer ensures a biocidal effect by inhibiting the metabolic pathways of microorganisms, contributing to the elimination of sources of unpleasant smells and the extension of the lifetime of the material. The additive is environmentally friendly, does not affect the physical properties of the polymers and does not cause degradation of the protected material. The component provides long-lasting microbiological protection (microbiological efficacy of $\geq 99.98\%$), as well as enhances the safety and attractiveness of the product. The additive is also very stable at high temperatures and in high humidity compared to traditionally used biocides.

PHYSICAL PROPERTIES			
Parameter	Standard	Value	Unit
Melt Volume-flow Rate (MVR)	ISO 1133	3	cm ³ /10min
Processing shrinkage	ISO 294-4, 2577	0.5	%
Density	ISO 1183	1050	kg/m ³
MECHANICAL PROPERTIES			
Parameter	Standard	Value	Unit
Modulus of rigidity when stretched	ISO 527	3300	MPa
Relative elongation at yield point	ISO 527	55	MPa
Elongation at break	ISO 527	3	%
Flexural modulus when stretched, 1h	ISO 899-1	3300	MPa
Charpy impact strength, +23°C	ISO 179/1eU	17	kJ/m ²
Izod impact strength	ISO 180/1A	2.5	kJ/m ²
Determination of hardness by ball indentation method	ISO 2039-1	150	MPa
THERMAL PROPERTIES			
Parameter	Standard	Value	Unit
Vicat softening point (A50; 500C/h 10N)	ISO 306	106	°C
Vicat softening point (B50 (50°C/h 50N))	ISO 306	101	°C
Coefficient of linear expansion	ISO 11359-1/-2	80	E-6/K

REPORT

Evaluation of the biocidal properties of PS-based composites

Materials and methods:

The experiment was performed according to ISO 22196: Plastic - Measurement of antibacterial activity on plastics and other non-porous surfaces.

Test microorganisms:

- *Escherichia coli* (ATCC 8739)
- *Staphylococcus aureus* (ATCC 6538)

Number of viable bacteria in the inoculum:

- *Escherichia coli* – 7.5×10^5 cfu·cm⁻³
- *Staphylococcus aureus* – 7.5×10^5 cfu·cm⁻³

Contact time:

- 24 hours

Table 1 Number of viable bacteria on control and test samples.

<i>Escherichia coli</i>						
Assessed parameter	Control sample immediately after inoculation	Control sample after 24 h	Sample with 2 wt.% after 24 h	Sample with 4 wt.% after 24 h	Sample with 6 wt.% after 24 h	Sample with 6 wt.% (dye) after 24 h
Average number of viable bacteria cells [cfu·cm ⁻²]	1.3×10^4	6×10^5	0	0	0	0
Average of the common logarithm of the number of viable bacterial cells	4.1	5.8	0	0	0	0
<i>Staphylococcus aureus</i>						
Assessed parameter	Control sample immediately after inoculation	Control sample after 24 h	Sample with 2 wt.% after 24 h	Sample with 4 wt.% after 24 h	Sample with 6 wt.% after 24 h	Sample with 6 wt.% (dye) after 24 h
Average number of viable bacteria cells [cfu·cm ⁻²]	1.3×10^4	1.2×10^5	6.0×10^3	1.4×10^2	1.4×10^2	7.8×10^1
Average of the common logarithm of the number of viable bacterial cells	4.1	5.1	3.8	2.2	2.2	1.9

PRODUCER:

Smart Nanotechnologies S.A.
Karola Olszewskiego 25,
32-566 Alwernia, Polska

smartnanotech.com.pl
phone: +48 12 25 89 395



Table 2 Antimicrobial activity and reduction of bacteria on tested surfaces.

Dosage	<i>E. coli</i>		<i>S. aureus</i>	
	Antimicrobial activity [log]	Reduction in number of bacteria [%]	Antimicrobial activity [log]	Reduction in number of bacteria [%]
2 wt. %	5.8	100	1.3	95.1
4 wt. %	5.8	100	2.9	99.8
6 wt. %	5.8	100	2.9	99.8
6 wt. % + dye	5.8	100	3.2	99.9

Graph 1. Antimicrobial activity and reduction of bacteria on tested surfaces.

